


Regudis W-HTE

Operating instructions

EN



	Page
1. General information	7
1.1 Validity of the instructions	7
1.2 Type plate	7
1.3 Scope of delivery	7
1.4 Contact	7
1.5 Symbols used	7
2. Safety-related information	7
2.1 Normative guidelines	7
2.2 Correct use	7
2.3 Modifications to the product	8
2.4 Warnings	8
2.5 Safety devices	8
2.5.1 Automatic closing mechanism for the control valve	8
2.6 Safety instructions	8
2.6.1 Danger due to insufficient personnel qualification	8
2.6.2 Danger to life due to electric current	9
2.6.3 Danger to life due to legionella formation	9
2.6.4 Risk of scalding due to hot water	9
2.6.5 Risk of injury from pressurised components	9
2.6.6 Risk of burns due to unintentionally escaping hot media	9
2.6.7 Risk of burns on hot components and surfaces	9
2.6.8 Risk of injury due to weight of the product	9
2.6.9 Risk of injury from improper work	9
2.6.10 Damage to property due to unsuitable location	9
2.6.11 Availability of the operating instructions	10
3. Technical description	11
3.1 Design	11
3.2 Functional description	12
3.3 System example with cabinet	13
3.4 Actuator with integrated potable water temperature control	13
3.4.1 Service mode	13
3.5 Installation scheme	14
3.6 Technical data	15
4. Accessories and spare parts	18
4.1 Accessories	18
4.2 Spare parts	18
5. Transport and storage	20
6. Mounting	20
6.1 Notes on mounting	20
6.2 Mounting options	20
6.3 Mounting of the station and accessories in a cabinet	20
6.3.1 Mounting of the cabinet	20
6.3.2 Mounting of the ball valve connection set	21
6.3.3 Mounting of the heating circuit connections fittings for an additional unmixed heating circuit	21

	Page
6.3.4 Mounting of the station	22
6.3.5 Mounting of the flow temperature control module	22
6.4 Wall mounting of the station	23
6.4.1 Wall mounting of the station	23
6.5 Mounting of the heat meter	24
6.6 Mounting of the water meter	25
6.7 Mounting of the potable water circulation module (optional)	26
6.8 Mounting of the derivative temperature control set (optional)	27
6.9 Electrical connection of the station	28
6.9.1 Connection of equipotential bonding	28
6.9.2 Electrical connection of the actuators and pump for the surface heating (if available)	29
6.9.3 Electrical connection of the circulation pump (if available)	29
6.9.4 Electrical connection of the station	29
7. Commissioning	30
7.1 Filling and venting of the heating circuit	30
7.2 Filling of the potable water circuit	31
7.3 Venting of the circulation pipe (if available)	31
7.4 Setting of the ball valves and valves for operation	32
7.5 Setting of the hot water temperature	32
7.5.1 Sliding hot water temperature control	32
7.6 Setting of the derivative temperature control set (if available)	33
7.7 Setting of the heating circuit temperature (if a flow temperature control module is available)	33
7.8 Teaching-in of the actuator	33
7.9 Instruction of the operator	33
8. Troubleshooting	34
8.1 Troubleshooting table	34
8.2 Status messages and error messages at the actuator	35
8.2.1 Status messages	36
8.2.2 Error messages	36
8.2.3 Fail-safe mode	37
8.2.4 Error reset	37
8.3 Calcification of the heat exchanger	37
8.3.1 Recognition of calcification	38
8.3.2 Removal and cleaning of the heat exchanger	38
8.4 Inspection and cleaning of the volume flow sensor	39
8.4.1 Inspection of the flow sensor	39
8.4.2 Cleaning of the volume flow sensor	39
8.5 Cleaning of the filter insert	41
9. Maintenance	41
9.1 Functional test of the check valve of the potable water circulation module	42
9.2 Leakage test (visual inspection)	42
9.3 Inspection of the electrical components and plug connections	42
9.4 Performance test of the heat exchanger	43
10. Notes for the operator	43
10.1 Setting of the hot water temperature	43
10.2 Legionella prevention	43

Regudis W-HTE

Table of contents

	Page
11. Dismantling and disposal	44
11.1 Dismantling	44
11.1.1 Disconnection of the station from the power supply	44
11.1.2 Dismantling of the station	44
11.2 Disposal	44
12. Appendix	45
12.1 Characteristic line for heating mode	45
12.2 Characteristic lines for potable water mode	46
12.3 Characteristic lines for performance range 1	48
12.4 Characteristic lines for performance range 2	52
12.5 Characteristic lines for performance range 3	56
12.6 Characteristic lines for double-walled version	60
12.7 Advice regarding corrosion protection	63
12.8 EU Declaration of conformity	65

1. General information

The original operating instructions are written in German.
The operating instructions in other languages have been translated from German.

1.1 Validity of the instructions

These instructions are valid for the Regudis W-HTE dwelling station.

Performance range 1

Heat exchanger copper brazed	Item no. 1344030
Heat exchanger copper brazed, Sealix® protective layer	Item no. 1344050

Performance range 2

Heat exchanger copper brazed	Item no.1344031
Heat exchanger copper brazed, Sealix® protective layer	Item no. 1344051

Performance range 3

Heat exchanger copper brazed	Item no. 1344032
Heat exchanger copper brazed, Sealix® protective layer	Item no. 1344052

Double-walled version

Heat exchanger copper brazed	Art-Nr. 1344070
------------------------------	-----------------

1.2 Type plate

The type plate (1) is located at the top left hand side of the lower shell.




Fig. 1: Position of the type plate

1 Type plate

1.3 Scope of delivery

Check your delivery for transport damage and completeness.

The scope of delivery includes:

- Regudis W-HTE dwelling station
- Operating instructions
- Fixing material
- Seal set

1.4 Contact

OVENTROP GmbH & Co. KG
Paul-Oventrop-Straße 1
59939 Olsberg
GERMANY
www.omentrop.com

Technical customer service
Phone: +49 (0) 29 62 82-234

1.5 Symbols used

	Highlights important information and further additions.
	Action required
	List
	Fixed order. Steps 1 to X.
	Result of action

2. Safety-related information

2.1 Normative guidelines

Observe the legal framework conditions applicable at the installation site.

The currently valid standards, rules and guidelines apply.

2.2 Correct use

Operational safety is only guaranteed if the product is used as intended.

The station is an electronically controlled product assembly with heat exchanger for use in domestic areas (e.g. rental units in residential, commercial or business areas). The product assembly provides heated potable water (hot water) within a residential unit and distributes the heating water (max. 90 °C).

Only use the product as intended:

- In technically perfect condition.
- Within the scope of the prescribed conditions of use.
- When all safety devices are fully functional.
- Following all instructions.
- Safety- and hazard-conscious.

- At locations directly connected to the public low-voltage grid.

Any use beyond and/or different from this is considered unintended use.

Claims of any kind against the manufacturer and/or his authorised representatives for damage resulting from unintended use cannot be recognised.

Intended use also includes correct compliance with these instructions.

2.3 Modifications to the product

Modifications to the product are not permitted. In case of modifications to the product, the warranty will become void. The manufacturer will not accept liability for damage and breakdowns caused by modifications to the product.

2.4 Warnings

Each warning contains the following elements:

Warning symbol **SIGNAL WORD**

Type and source of danger

Possible consequences if the danger occurs or the warning is ignored.

- ! Ways to avoid the danger.

Signal words define the severity of the danger posed by a situation.

DANGER

Indicates an imminent danger with high risk. If the situation is not avoided, death or most serious bodily injuries will result.

WARNING

Indicates a possible danger with moderate risk. If the situation is not avoided, death or serious bodily injuries may result.

CAUTION

Indicates a possible danger with lower risk. If the situation is not avoided, minor and reversible bodily injuries will result.

NOTICE

Indicates a situation that can potentially result in damage to property if not avoided.

2.5 Safety devices

2.5.1 Automatic closing mechanism for the control valve




Fig. 2: Control valve closes in case of power failure

If the power supply is interrupted (failure 230 V), then the control valve closes permanently to completely interrupt the heating water flow into the heat exchanger. This excludes the possibility of uncontrolled heating of the potable water.

2.6 Safety instructions

We have developed this product in accordance with current safety requirements.

Observe the following instructions for safe use.

2.6.1 Danger due to insufficient personnel qualification

Work on this product may only be carried out by suitably qualified specialist tradespeople.

Due to their professional training and experience as well as knowledge of the relevant legal regulations, qualified specialist tradespeople are able to carry out work on the described product in a professional manner.

Electrician

The following work may only be carried out by qualified electricians:

- Connecting the product to the power supply.
- Due to their professional training and experience as well as knowledge of the relevant standards, qualified electricians are able to carry out work on electrical installations and connections. He must be able to recognise possible dangers independently.

Specialist sanitary, heating and air-conditioning tradespeople

The following work may only be carried out by specialist sanitary, heating and air-conditioning tradespeople:

- Mounting
- Commissioning
- Troubleshooting

- Maintenance
- Dismantling and disposal

Due to their professional training and experience as well as knowledge of the relevant standards, specialist sanitary, heating and air-conditioning tradespeople are able to carry out work on heating, cooling and potable water installations. He must be able to recognise possible dangers independently.

Operator

The following work may be carried out by the operator:

- Operation of the product

The operator must be instructed in the operation by specialist tradespeople.

2.6.2 Danger to life due to electric current

Work on the power supply may only be carried out by a qualified electrician.

- ! Disconnect the station from the power supply at all poles and secure it against being switched on again.
- ! Check that no voltage is present.
- ! Only install the product in dry indoor areas.

2.6.3 Danger to life due to legionella formation

- ! Ensure the following:
- The temperature of the potable water in the cold water pipe must not exceed 25 °C.
- The water in the potable water circuit must be completely replaced after 72 hours at the latest.
- When using the potable water circulation module, the hot water temperature must be at least 60 °C. The temperature difference between the hot water outlet of the heat exchanger and the return of the circulation pipe at the station must not exceed 5 °C.



Observe the relevant regulations (e.g. DVGW work sheet W551).

2.6.4 Risk of scalding due to hot water

Due to faulty settings or defects, the hot water temperature at the draw-off points can rise up to the heating water temperature in the buffer storage cylinder.

- ! If there is a risk of scalding in accordance with DIN EN 806 and DIN 1988 due to high heating water temperature in the buffer storage cylinder, you must install scald protection at all draw-off points.
- ! If the heating water temperature in the buffer storage cylinder is low, resulting in a low hot water temperature without risk of scalding at the draw-off points, you must instruct the system operator to ensure the low heating water temperature in the buffer storage cylinder all year round.

2.6.5 Risk of injury from pressurised components

- ! Only carry out work on the heating circuit or the potable water circuit when the system is depressurised.
- ! Adhere to the permissible operating temperatures during operation.
- ! Install a non-shut off safety valve in the potable water heating system (regulation according to DIN EN 806-2).

2.6.6 Risk of burns due to unintentionally escaping hot media

- ! Only carry out work on the heating circuit of the potable water circuit when the system is depressurised.
- ! Allow the product to cool down before working on it.
- ! Check that the product is not leaking after work is complete.
- ! Wear safety goggles.

2.6.7 Risk of burns on hot components and surfaces

- ! Allow the product to cool down before working on it.
- ! Wear suitable protective clothing to avoid unprotected contact with hot fittings and system components.

2.6.8 Risk of injury due to weight of the product

- ! Always wear safety shoes during installation.

2.6.9 Risk of injury from improper work

Stored energy, angular components, points and corners on an in the product can cause injuries.

- ! Ensure there is sufficient space before starting work.
- ! Handle open or sharp-edged components with care.
- ! Keep the working area tidy and clean to avoid sources of accidents.

2.6.10 Damage to property due to unsuitable location

- ! Do not install the product in rooms prone to frost.
- ! Do not install the product in rooms with corrosion-enhancing ambient air.
- ! Observe the notes on corrosion protection in the appendix.

2.6.11 Availability of the operating instructions

Every person who works with this product must have read and apply this manual and all applicable instructions (e.g. accessories instructions).

The instructions must be available at the place of use of the product.

- ! Pass on these instructions and all applicable instructions (e.g. accessories instructions) to the operator.

3. Technical description

3.1 Design




Fig. 3: Overview of the Regudis W-HTE dwelling station

- | | |
|---|---|
| 1 Type plate | 11 Spacer for heat meter |
| 2 Wall bracket | 12 Zone valve for heating circuit control |
| 3 Thermally insulated lower shell | 13 Hot water temperature sensor |
| 4 Connection for the circulation pipe | 14 Heat exchanger |
| 5 Volume flow sensor | 15 Control valve with integrated differential pressure and volume flow control |
| 6 Spacer for water meter | 16 Vent valve in the heating circuit |
| 7 Drain valve in the primary circuit | 17 Actuator with integrated potable water temperature control |
| 8 Connection for derivative temperature control set | 18 Rotary knob |
| 9 Filter insert in the primary supply | 19 Connection box for power supply |
| 10 Connection in the primary supply for temperature sensor of the heat meter | |

3.2 Functional description

The Regudis W-HTE is an electronically controlled product assembly for use in domestic areas. The product assembly provides heated potable water (hot water) within a residential unit and distributes the heating water (max. 90 °C) to radiators. With an optional flow temperature control module, heating water distribution to a surface heating system (e.g. underfloor heating) is also possible.

The decentralised hot water preparation of the station makes the storage of hot potable water unnecessary.

In the heat exchanger (14), potable water is heated according to the continuous flow principle only when it is needed. The demand for hot water is detected by the volume flow sensor (5).

The setpoint temperature for the hot water is adjusted with the rotary knob (18) on the actuator (17). During operation, the temperature sensor continuously measures the temperature of the hot water at the hot water outlet of the heat exchanger. The temperature sensor forwards this information to the electronic control.

The information from the volume flow sensor and the temperature sensor is passed on to the actuator by the electronic control.

The actuator opens and closes the control valve (15). Depending on the position of the control valve, more or less hot heating water flows from the primary supply into the heat exchanger as required.

In addition, the control valve keeps the necessary differential pressure in the system constant.

The heat output transferred to the potable water depends on the heating water quantity and the heating water temperature supplied to the heat exchanger.

A potable water priority circuit is integrated into the control valve, which ensures the provision of the required hot water quantity even in heating mode.

Optionally, an actuator can be mounted on the zone valve (12). This offers you the possibility to close the zone valve time-controlled.

The Regudis W-HTE dwelling station is available in different performance ranges and versions (see charts in the appendix).

The performance ranges differ due to the size of the heat exchanger.

The double-walled version of the dwelling station is equipped with a double-walled heat exchanger and has a leakage detection device on the underside. As soon as there is a leak in one of the plates of the heat exchanger, water escapes through the leakage detection device.




Fig. 4: Heating mode




Fig. 5: Hot water mode

- 1 Hot water outlet
- 2 Heating circuit return
- 3 Heating circuit supply
- 4 Primary supply from the buffer storage cylinder
- 5 Primary return to the buffer storage cylinder
- 6 Cold water outlet
- 7 Cold water inlet from the house connection

3.3 System example with cabinet




Fig. 6: System example with cabinet, potable water circulation and surface heating

- 1 Connecting block for room thermostats and actuators
- 2 Station
- 3 Potable water circulation module
- 4 Ball valve connection set
- 5 Manifold for surface heating
- 6 Actuator for surface heating
- 7 Flow temperature control module for surface heating
- 8 Derivative temperature control set
- 9 Zone valve (can be optionally equipped with an actuator)
- 10 Actuator with integrated potable water temperature control

3.4 Actuator with integrated potable water temperature control





Fig. 7: Actuator with integrated potable water temperature control

- 1 Two-pole plug (power supply)
- 2 Three-pole socket (volume flow sensor)
- 3 Two-pole socket (hot water temperature sensor)
- 4 Indicator light (LED)
- 5 Error reset index (only for specialist tradespeople)
- 6 Service mode index (only for specialist tradespeople)
- 7 Rotary knob for hot water temperature, error reset and service mode
- 8 Temperature scale for hot water temperature in °C (here: 60 °C, factory setting)

 Make sure the polarity is correct (the plugs are coded).

3.4.1 Service mode

 The actuator is closed when delivered.

If you set the rotary knob to the service mode index (6) for more than 5 seconds, the actuator opens the control valve completely.

The service mode facilitates the dismantling of the actuator and can be helpful during commissioning to vent the primary circuit.

The control valve remains completely open until you turn the rotary knob back to the desired hot water temperature (< 70 °C).

3.5 Installation scheme




Fig. 8: Installation scheme: dwelling station

- | | |
|--|-------------------------------|
| 1 Radiator (heating circuit) | 12 Circulation circuit |
| 2 Dwelling station | 13 Hot water |
| 3 Ball valves | 14 Cold water |
| 4 Surface heating (heating circuit) | |
| 5 Flow temperature control module for surface heating | |
| 6 Primary return | |
| 7 Primary supply | |
| 8 Cold water inlet | |
| 9 Pump group | |
| 10 Buffer storage cylinder | |
| 11 Heat generator | |

Regudis W-HTE

Technical description

3.6 Technical data

General information

Max. operating pressure p_s	10 bar
Max. operating temperature t_s	90 °C
Ambient temperature T	2 to 35 °C
Empty weight	Performance range 1:7.7 kg
	Performance range 2:8.8 kg
	Performance range 3:10.2 kg
	Double-walled version: 13,3 kg

Electrical connection: Power supply unit

Mains input voltage	100 to 240 V AC ± 10 %
Mains input frequency	50 to 60 Hz
Output voltage	5 V DC +7.5 %, -5 %
Rated output current	max. 1200 mA
Protection: Connection box	IP66
Protection class	II
Overvoltage category	III
Ambient temperature	0 to 60 °C

Electrical connection: Actuator

Input voltage	5 DC +7.5 %, -5 %
Power consumption	0.15 to 3 W
Protection type	IP54
Ambient temperature	0 to 60 °C

Dimensions

Width x Height x Depth	600 x 455 x 110 mm
Connections	G 3/4 union nut, flat sealing
Centre distance of the connections	65 mm
Centre distance to the wall	26.5 mm

Primary circuit (buffer storage cylinder)

Fluid	Heating water according to VDI 2035/Ö-Norm H 5195-1 (Austrian standard, fluid category ≤ 3 according to EN 1717, observe the specifications of the Oventrop information sheet on corrosion protection in the appendix
Min. differential pressure	150 mbar

Max. differential pressure	2.0 bar
Min. flow temperature	See charts in the appendix.

Heating circuit (radiators)

Fluid	Same as in the primary circuit.
Max. Volume flow	600 l/h
Differential pressure control	150 mbar

Potable water circuit

Fluid	Potable water (see Oventrop information sheet on corrosion protection in the appendix)
-------	--

NOTICE

Damage to the slide-in turbine due to chemical influences!

Additives for water treatment in high concentrations can damage the slide-in turbine.

! Make sure that the permissible limits for potable water are not exceeded.

Min. cold water pressure	See charts in the appendix.
Control range	40 to 70 °C
Max. Hot water volume flow	See charts in the appendix.

Material

Heat exchanger copper brazed	Plates: Stainless steel 1.4401 Connections: Stainless steel 1.4404 Brazing material: Copper
Heat exchanger copper brazed, Sealix®-protective layer	Plate material: Stainless steel 1.4401 Connections: Stainless steel 1.4404 Brazing material: Copper Protective layer: SiO2 basis
Pipes	Stainless steel 1.4404
Valves and fittings	Brass and bronze
Temperature sensor	Stainless steel 1.4404
Volume flow sensor	Brass and plastic
Spacers for meters	Plastic
Seals	EPDM and fibre materials
Thermal insulation	Expanded polypropylene

Regudis W-HTE

Technical description

Torques

Union nuts G $\frac{3}{4}$	45 Nm
Union nuts G 1	45 Nm
Spacers for meters ((6) and (11) in Fig. 3 on page 11)	30 Nm
Temperature sensor ((13) in Fig. 3 on page 11)	15 Nm
Filter insert ((9) in Fig. 3 on page 11)	15 Nm
Drain valve ((7) in Fig. 3 on page 11)	15 Nm
Vent valve ((16) in Fig. 3 on page 11)	15 Nm




Fig. 9: Dimensions

Regudis W-HTE

Technical description




Fig. 10: Connection assignment

1	Hot water outlet
2	Heating circuit return
3	Heating circuit supply
4	Primary supply from the buffer storage cylinder
5	Primary return to the buffer storage cylinder
6	Cold water outlet
7	Cold water inlet from the house connection
Black	Hot water
Grey	Cold water

4. Accessories and spare parts

4.1 Accessories

Designation	Item no.
Ball valve connection set	1344480
Ball valve connection set with flushing function	1344485
Ball valve connection set for the potable water circulation module	1344484
Connection and shutoff set	1344680
Connection and shutoff set with flushing function	1344685
Connection and shutoff set for the potable water circulation module	1344684
Potable water circulation module	1344555
Derivative temperature control set	1344490
Flow temperature control module	1344550
	1344552
	1344554
Heating circuit connection fitting	1344551
Instantaneous water heater module	1344560
Duo heating circuit separation module	1344576
Connection module	1344570
Stainless steel spacer	1349052
Flushing and mounting bridge	1344489
Automatic deaerator	1344460
Flush-mounted cabinet	1344596
	1344598
	1344599
Surface-mounted cabinet	1344697
	1344698
	1344699
Regubox exclusive surface-mounted bonnet	1344595
Earthing clamp	1341092
Sealing plug set	1344481

Front thermal insulation shell	1344470
Connecting block for room thermostats and actuators with pump logic	e. g. 1400983
Manifold	e. g. 1406362
Actuator	e. g. 1012452

4.2 Spare parts

Designation		Item no.
Heat exchanger copper brazed	Performance range 1	1344083
	Performance range 2	1344084
	Performance range 3	1344085
Heat exchanger copper brazed, Sealix®-protective layer	Performance range 1	1344093
	Performance range 2	1344094
	Performance range 3	1344095
Actuator with integrated potable water temperature control		1344491
Temperature sensor		1344494
Volume flow sensor in a housing		1344493
Filter insert		1344495
Control valve with integrated differential pressure and volume flow control		1344492
Sealing ring (5 pieces for G ¾ junctions)		1344497
Sealing ring (5 pieces for G 1 junctions)		1344498
Power supply unit 100 - 240 V, ~50 - 60 Hz		1344496

Regudis W-HTE

Accessories and spare parts




Fig. 11: Spare parts

- 1** Actuator with integrated potable water temperature control
- 2** Power supply unit 100 - 240 V, ~50 - 60 Hz (in connection box)
- 3** Volume flow sensor in a housing
- 4** Filter insert
- 5** Sealing ring (5 pieces for G 3/4 junctions)
- 6** Sealing ring (5 pieces for G 1 junctions)
- 7** Temperature sensor
- 8** Heat exchanger
- 9** Control valve with integrated differential pressure and volume flow control

5. Transport and storage

Transport the product in its original packaging.

Store the product under the following conditions:

Temperature range	0 °C to +40 °C
Particles	Store in a dry and dust-protected place
Mechanical influences	Protected from mechanical shock
Radiation	Protected from UV rays and direct sunlight
Chemical influences	Do not store together with solvents, chemicals, acids, fuels or similar substances

6. Mounting

WARNING

Risk of injury from pressurised components!

Media escaping under pressure can cause injuries.

- ! Only carry out installation work when the system is depressurised.
- ! For retrofitting an existing system: Drain the system or shut off the supply pipes of the system section and depressurise the system section.
- ! Any work on the system may only be carried out by specialist tradespeople.

CAUTION

Risk of injury due to the heavy weight of the station

The station is heavy. Falling down can cause injuries.

- ! Always wear safety shoes during installation.

CAUTION

Risk of injury from improper work!

Angular components, points and corners on an in the product can cause injuries.

- ! Handle open or sharp-edged components with care.

6.1 Notes on mounting

Before mounting the station, make sure that:

- pipework to the installation site has been laid, flushed and checked for leaks.
- a power cable and an earthing cable have been laid to the installation site.



For the electrical connection, observe chapter 5.3.2 of EN60204-1.

- Mount the station in a dry, frost-free room in which the ambient temperature does not exceed 35 °C during operation.
- Always mount the station upright, never inclined or lying down.
- The station must always be freely accessible even after mounting.

6.2 Mounting options

The station is suitable for mounting in different installation situations:

- In a surface-mounted cabinet
- In a flush-mounted cabinet
- Onto a wall, optionally with surface-mounted bonnet

6.3 Mounting of the station and accessories in a cabinet

6.3.1 Mounting of the cabinet




Fig. 12: Preparation of the Oventrop cabinet

- 1 Cabinet
- 2 Threaded bolts for the station

Regudis W-HTE

Mounting

3 Threaded bolts for the ball valve connection set

4 Horizontal and vertical fastening rails for the manifold



Please observe the separate operating instructions of the cabinet.

► Mount the cabinet as described in the separate operating instructions of the cabinet.

6.3.2 Mounting of the ball valve connection set




Fig. 13: Mounting of the ball valve connection set

1 Threaded bolts

2 Ball valve connection set



Please observe the separate operating instructions of the ball valve connection set.



Fixing material is included with the cabinet.

1 Slide the rubber washers onto the threaded bolts (1) in the cabinet.

2 Push the ball valve connection set (2) onto the threaded bolts.

3 Align the ball valve connection set horizontally.

4 Slide the washers onto the threaded bolts.

5 Screw the ball valve connection set onto the threaded bolts with the hexagon nuts.

6 Close all ball valves.

7 Connect the pipework to the ball valves.



The screed cover can be dismantled for pipe installation, it must be mounted during masonry, plastering and screed work.

► The ball valve connection set is mounted in the cabinet.

6.3.3 Mounting of the heating circuit connections fittings for an additional unmixed heating circuit

Only if you use an additional unmixed heating circuit in conjunction with a flow temperature control module:



Please observe the separate operating instructions of the heating circuit connection fittings.

► Fit the heating circuit connection fittings to the heating circuit return and to the heating circuit supply.

6.3.4 Mounting of the station




Fig. 14: Mounting of the station

- 1 Station
- 2 Threaded bolts

 Fixing material is included with the cabinet.

- 1 Slide the rubber washers onto the threaded bolts (2) in the cabinet.
 - 2 Position the seals on the individual ball valves of the ball valve connection set.
 - 3 Slide the station (1) onto the threaded bolts (2) in the cabinet at the top and onto the connections of the ball valves at the bottom.
 - 4 Align the station horizontally.
 - 5 Screw the station to the ball valves.
 - 6 Slide the washers onto the threaded bolts.
 - 7 Screw the station to the threaded bolts with the hexagon nuts.
- ▶ The station is mounted in the cabinet.

6.3.5 Mounting of the flow temperature control module




Fig. 15: Mounting of the flow temperature control module

- 1 Vertical mounting rail
- 2 Spacer sleeve
- 3 Brackets for the manifold
- 4 Screws with spacer sleeve
- 5 Horizontal mounting rail
- 6 Upper distributor (heating circuit supply)
- 7 Pipework
- 8 Actuator
- 9 Lower collector (heating circuit return)
- 10 Pipework
- 11 Brackets for the manifold
- 12 Connections for the flow temperature control module
- 13 Flow temperature control module
- 14 Flexible pipes
- 15 Heating circuit connection fittings (optional for an additional unmixed heating circuit)

Regudis W-HTE

Mounting



Please observe the separate operating instructions of the flow temperature control module.

- 1 Align the vertical mounting rails (1) in the horizontal mounting rails (5) to fit the brackets (3) and (11) for the manifold.
 - 2 Loosely screw the brackets (3) with the spacer sleeves (2) to the prepared vertical mounting rails (1).
 - 3 Loosely mount the upper distributor (6) to the brackets (3). Position the sealing surface of the connection (12) of the upper distributor (6) at a distance of approx. 65 mm from the left-hand cabinet wall.
 - 4 Screw the vertical mounting rails (1) to the horizontal mounting rails (5).
 - 5 Align the upper distributor (6) horizontally.
 - 6 Screw the brackets (3) to the vertical mounting rails (1) using the screws with spacer sleeve (4).
 - 7 Connect the pipework (7) to the upper distributor (6).
 - 8 Loosely mount the lower collector (9) in the brackets (11).
 - 9 Connect the pipework (10) to the lower collector (9).
 - 10 Screw the distributor (6) and the collector (9) to the brackets (3) and (11).
 - 11 Mount the flow temperature control module (13) to the connections (12) of the distributor (6) and the collector (9).
 - 12 Connect the flow temperature control module (13) to the station's ball valve connection set via the flexible pipes (14). Only if you use the heating circuit connection fittings (15) for an additional unmixed heating circuit: Connect the flow temperature control module (13) to the lateral connections of the heating circuit connection fittings.
 - 13 Only if available: Mount the actuators (8) on the lower collector (9).
- ▶ The flow temperature control module is mounted in the cabinet.

6.4 Wall mounting of the station

Wall mounting of the ball valve connection set




Fig. 16: Mounting of the ball valve connection set

- 1 Drill holes
- 2 Carrier rail



Please observe the separate operating instructions of the ball valve connection set.

- 1 Have suitable fixing materials ready.
 - 2 Position the ball valve connection set horizontally on the wall.
 - 3 Mark the drill holes (1) through the holes in the carrier rail (2).
 - 4 Drill holes in the wall at the markings and insert dowels.
 - 5 Align the ball valve connection set horizontally on the wall and screw it into the dowels with screws and washers.
 - 6 Close all ball valves.
 - 7 Connect the pipework to the ball valves.
- ▶ The ball valve connection set is mounted on the wall.

6.4.1 Wall mounting of the station




Fig. 17: Alignment and marking of the station

- 1 Bore holes
- 2 Station

- 1 Have suitable fixing materials ready.
- 2 Lift the station (2) onto the connections of the ball valves and position the station horizontally on the wall.
- 3 Mark the drill holes through the bore holes (1) of the lower shell and the wall bracket ((3) and (2) in Fig. 3 on page 11).
- 4 Lift the station from the wall.





Fig. 18: Mounting of the station

- 1** Dowel
 - 2** Washer
 - 3** Screw
 - 4** Station
- 5** Drill holes in the wall at the markings and insert the dowels (1).
-
-  Make sure that no dirt enters the ball valve connection set.
-
- 6** Lift the station (4) onto the connections of the ball valves.
 - 7** Align the station horizontally on the wall and screw the station into the dowels with the screws (3) and washers (2) through the bore holes in the lower shell and wall bracket.
- ▶ The station is mounted on the wall.

6.5 Mounting of the heat meter



The factory-fitted meter spacers are used for commissioning/pressure testing and are not suitable for continuous operation. If no meters are fitted, use the stainless steel spacers from the accessories range.

The heat meter must have the following characteristics:



- Fast sampling rate (approx. 4 s)
- Housing length: 110 mm
- Connections: G $\frac{3}{4}$
- $q_p = 1.5 \text{ m}^3/\text{h}$ according to MID directive 2014/32/EU
- Integrated return temperature sensor
- Flow temperature sensor M10x1 according to DIN EN 1434-2, sensor type DS 27.5 ($\leq \text{Ø}5.6$).
- No inlet or outlet sections required
- Lowest possible pressure loss

Suitable are, for example, heat meters that measure according to the ultrasonic principle and also record short water tapings.

WARNING

Risk of injury from pressurised components!

Media escaping under pressure can cause injuries.

- ! Only carry out installation work when the system is depressurised.
- ! For retrofitting an existing system: Drain the system or shut off the supply pipes of the system section and depressurise the system section.
- ! Wear safety goggles.

CAUTION

Risk of scalding due to hot media!

If the station has been in operation, there is a risk of scalding due to unintentional escape of hot water or steam.

- ! Allow the system to cool down.
- ! Wear safety goggles.

CAUTION

Risk of burns on hot components!

Touching hot components can cause burns.

- ! Wear safety gloves.





Fig. 19: Mounting of the heat meter

- 1 Spacer
- 2 Plug
- 3 Drain valve
- 4 Primary return
- 5 Primary supply
- 6 Heating circuit supply
- 7 Heating circuit return
- 8 Vent valve

 Please observe the separate operating instructions of the heat meter.

- 1 Close the ball valves in the primary supply (5), primary return (4), heating circuit supply (6) and heating circuit return (7).
- 2 Open the control valve ((15) in Fig. 3 on page 11) by disassembling the actuator ((17) in Fig. 3 on page 11).

Connect a hose line to the drain valve ((7) in Fig. 3 on page 11) in the primary circuit to make it easier to direct escaping water into a container.

Have a cloth and a container ready to catch any water that escapes.

- 3 Slowly open the vent valve (8) and the drain valve (3).
- 4 When the primary circuit above the drain valve is empty, close the drain valve (3) and the vent valve (8) again.
- 5 Remove the spacer (1) from the pipe.
- 6 Install the heat meter with seals in the pipe.
- 7 Unscrew the plug (2) from the connection for the temperature sensor of the heat meter in the primary supply.

- 8 Screw the temperature sensor into the connection in the primary supply.
- 9 Slowly open the ball valves in the primary return (4) and the primary supply (5).
- 10 Open the vent valve (8) slightly.
- 11 As soon as no more water escapes, close the vent valve.
- 12 Close the control valve ((15) in Fig. 3 on page 11) by mounting the actuator ((17) in Fig. 3 on page 11).
- 13 Check all components and screw connections for leaks.
- 14 Tighten any screw connections that are too loose.
- 15 Seal the heat meter.




Fig. 20: Recess and cable guides in the lower shell


- 1 Recess
- 2 Cable guide

- 16 To fix the cables, guide the individual cables through the cable guides (2).
- 17 Put the cables together and push them through the recess (1) and behind the lower shell.

▶ The heat meter is mounted.

6.6 Mounting of the water meter

The water meter must have the following characteristics:

-  • Housing length: 110 mm
- Connections: G 3/4
- Q3 = 2.5 m³/h according to MID directive 2014/32/EU

⚠ WARNING

Risk of injury from pressurised components!

Media escaping under pressure can cause injuries.

- ! Only carry out installation work when the system is depressurised.
- ! For retrofitting an existing system: Drain the system or shut off the supply pipes of the system section and depressurise the system section.
- ! Wear safety goggles.

⚠ CAUTION

Risk of burns on hot components!

Touching hot components can cause burns.

- ! Wear safety gloves.




Fig. 21: Mounting of the water meter

- 1 Spacer
- 2 Coupling
- 3 Cold water inlet
- 4 Cold water outlet



Please observe the separate operating instructions of the water meter.



Have a cloth and a container ready to catch any water that escapes.

- 1 Close the ball valves in the cold water inlet (3) and cold water outlet (4).
- 2 Open a draw-off point to depressurise the potable water circuit.
- 3 When the potable water circuit is depressurised, close

the draw-off point again.

- 4 Loosen the union nut of the coupling (2).
 - 5 Remove the spacer (1) with the coupling from the pipe.
 - 6 Unscrew the coupling from the spacer.
 - 7 Screw the coupling to the water meter.
 - 8 Install the water meter in the pipe.
 - 9 Slowly open the ball valves in the cold water outlet (4) and cold water inlet (3).
 - 10 Check all components and screw connections for leaks.
 - 11 Tighten any screw connections that are loose.
 - 12 Seal the water meter.
 - 13 Open a draw-off point to vent the potable water pipe.
 - 14 As soon as water escapes without bubbles, close the draw-off point again.
- ▷ The water meter is mounted.

6.7 Mounting of the potable water circulation module (optional)

⚠ WARNING

Risk of injury from pressurised components!

Media escaping under pressure can cause injuries.

- ! Only carry out installation work when the system is depressurised.
- ! For retrofitting an existing system: Drain the system or shut off the supply pipes of the system section and depressurise the system section.
- ! Wear safety goggles.

⚠ CAUTION

Risk of scalding due to hot media!

If the station has been in operation, there is a risk of scalding due to unintentional escape of hot water or steam.

- ! Allow the system to cool down.
- ! Wear safety goggles.

⚠ CAUTION

Risk of burns on hot components!

Touching hot components can cause burns.

- ! Wear safety gloves.

Regudis W-HTE

Mounting




Fig. 22: Mounting of the potable water circulation module

- 1** Volume flow sensor
- 2** Circulation pipe
- 3** Vent valve
- 4** High-efficiency pump
- 5** Ball valve connection set for the potable water circulation module
- 6** Cold water inlet
- 7** Cold water outlet



Please observe the separate operating instructions of the potable water circulation module.

- 1** Close the ball valves in the cold water inlet (6) and cold water outlet (7).
- 2** Mount the ball valve connection set (5) for the potable water circulation module with a centre distance of 65 mm to the cold water outlet of the station. In a cabinet, mount the ball valve connection set on the threaded bolt pre-mounted for this purpose.
- 3** Open a draw-off point to depressurise the potable water circuit.
- 4** When the potable water circuit is depressurised, close the draw-off point again.
- 5** Unscrew the cap for the circulation connection from the volume flow sensor (1).
- 6** Screw the circulation pipe (2) to the volume flow sensor and the ball valve connection set for the potable water circulation module (5).
- 7** Slowly open the ball valves in the circulation pipe (5), cold water outlet (7) and cold water inlet (6).
- 8** Open the vent valve (3) in the potable water circuit slightly.

- 9** As soon as water escapes without bubbles, close the vent valve.
 - 10** Check all components and screw connections for leaks.
 - 11** Tighten any screw connections that are too loose.
 - 12** Connect the high-efficiency pump (4) to the system control via the time switch supplied.
- ▶ The potable water circulation module is mounted.

6.8 Mounting of the derivative temperature control set (optional)




Fig. 23: Draining of the station (primary circuit)

- 1** Drain valve
- 2** Primary return
- 3** Primary supply
- 4** Heating circuit supply
- 5** Heating circuit return
- 6** Plug
- 7** Vent valve

- 1** Close the ball valves in the primary supply (3), primary return (2), heating circuit supply (4) and heating circuit return (5).
- 2** Open the control valve ((15) in Fig. 3 on page 11) by disassembling the actuator ((17) in Fig. 3 on page 11).



Connect a hose line to the drain valve ((7) in Fig. 3 on page 11) in the primary circuit to make it easier to direct escaping water into a container.

Have a cloth and container ready to catch any water that escapes.

- 3** Slowly open the vent valve (7) and the drain valve (1).
- 4** When the primary circuit above the drain valve is empty, close the drain valve (1) and the vent valve (7).

Regudis W-HTE

Mounting

again.

- 5 Unscrew the plug (6) from the connection of the pipe in the primary supply.






Fig. 24: Mounting of the derivative temperature control set

- 1 Rotating cap
- 2 Index ring
- 3 Index
- 4 Valve

 Please observe the separate operating instructions of the derivative temperature control set.

- 6 Screw the valve (4) of the derivative temperature control set into the connection of the pipe.
 - 7 Place the index ring (2) on the valve so that the index (3) is clearly visible from the front.
 - 8 Align the rotating cap (1) so that the index points to 35 °C and place the rotating cap on the valve.
 - 9 Slowly open the ball valves in the primary return ((2) in Fig. 23 on page 27) and the primary supply ((3) in Fig. 23 on page 27).
 - 10 Open the derivative temperature control set completely.
 - 11 Open the vent valve ((7) in Fig. 23 on page 27) slightly.
 - 12 As soon as water escapes without bubbles, close the vent valve.
 - 13 Close the control valve ((15) in Fig. 3 on page 11) by mounting the actuator ((17) in Fig. 3 on page 11).
 - 14 Check all components and screw connections for leaks.
 - 15 Tighten any screw connections that are too loose.
- ▶ The derivative temperature control set is mounted.

 For setting the temperature, see section 7.6 on page 33.

6.9 Electrical connection of the station

DANGER

Danger to life due to electric current!

There is a danger to life if live components are touched.

- ! Disconnect the station from the power supply at all poles and secure it against being switched on again.
- ! Check that no voltage is present.
- ! The connection may only be carried out by a qualified electrician.

6.9.1 Connection of equipotential bonding

Protective equipotential bonding establishes a connection with good electrical conductivity between conductive bodies of electrical equipment and the main equipotential bonding bar (main earthing bar) of the building. (According to DIN VDE 0100, bodies are touchable conductive parts which, in contrast to the "active parts" of the equipment, can only be live as a result of a fault).



This measure serves to protect against electric shock and is standardised in IEC 60364-4-41:2005 and DIN VDE 0100-410:2007-06.

The technical design for equipotential bonding is standardised in IEC 60364-5-54:2011 and DIN VDE 0100-540:2012-06.

- ▶ Comply with applicable standards and country-specific regulations.

DANGER

Danger to life due to electric current!

There is a danger to life if live components are touched.

- ! The connection may only be carried out by a qualified electrician.




Fig. 25: Earthing of the station

- ▶ If equipotential bonding of the station is not provided, e.g. by mounting it in an earthed cabinet, then mount an earthing clamp (Ø 18 mm) on the station's pipework in the area marked in grey (1).
- ▶ Connect the earthing clamp to a suitable equipotential bonding bar in the building using an equipotential bonding conductor made of copper with a cross section of at least 6 mm².

6.9.2 Electrical connection of the actuators and pump for the surface heating (if available)

⚠ DANGER

Danger to life due to electric current!

There is a danger to life if live components are touched.

- ! The connection may only be carried out by a qualified electrician.




Fig. 26: Electrical connection of the actuators and pump for the surface heating

- 1 Connecting block for room thermostats and actuators
- 2 Circulation pump
- 3 Actuator for the surface heating
- 4 Pump for the surface heating

5 Contact thermostat



Please observe the separate operating instructions of the pump, actuators and contact thermostat.

- ▶ Connect the surface heating pump (4), the actuators (3) and the contact thermostat (5) to the power supply in the connecting block (1) according to the separate operating instructions.

6.9.3 Electrical connection of the circulation pump (if available)



Please observe the separate operating instructions of the circulation pump.

- ▶ Connect the circulation pump (2) to the power supply according to the separate operating instructions.
- ▶ Set the time switch according to the separate operating instructions.

6.9.4 Electrical connection of the station



DANGER

Danger to life due to electric current!

There is a danger to life if live components are touched.

- ! Disconnect the station from the power supply at all poles and secure it against being switched on again.
- ! Check that no voltage is present.
- ! The connection box must only be opened by a qualified electrician.




Fig. 27: Electrical connection of the station

- 1 Power supply cable
- 2 Power supply unit cable
- 3 Connection box
- 4 Terminal

5 Cover

6 Screw

- 1** Loosen the screws (6) and remove the cover (5) of the connection box (3).
 - 2** Connect the power supply cable (1) to the prepared terminals (4) in the connection box.
 - 3** Screw the cover onto the connection box.
 - 4** Connect the station to the power supply.
- ▶ Mounting is complete.

7. Commissioning

⚠ CAUTION

Risk of scalding due to hot media!

During some work, the station has to remain in operation and there is a risk of scalding due to unintentional escape of hot water or steam.

! Wear safety goggles during all work.

⚠ CAUTION

Risk of burns on hot components!

Touching hot components can cause burns.

! Wear safety gloves.

7.1 Filling and venting of the heating circuit

⚠ CAUTION

Risk of scalding due to hot media!

If the heating system has been in operation and the connected buffer storage cylinder is heated, there is a risk of scalding due to unintentional escape of hot water or steam.

! Check all screw connections during filling and tighten any leaking screw connections.




Fig. 28: Filling and venting of the heating circuit

- 1** Drain valve
- 2** Primary return
- 3** Primary supply
- 4** Heating circuit supply
- 5** Heating circuit return
- 6** Vent valve

NOTICE

Risk of damage due to pressure surge!

The abrupt injection of water into the station can lead to damage, e.g. to the sensors or sealing points.

! Always open the ball valves slowly.

i During filling and venting of the heating circuit, ensure that the heating circuit is filled and the system pressure is kept constant.

i The actuator is closed when delivered. In the closed state, there is no flow through the heat exchanger. To allow flow through the heat exchanger, set the actuator to the service mode index (see section 3.4.1 on page 13)

- 1** Check that the drain valve (1) and the vent valve (6) in the primary circuit are closed.
- 2** Slowly open the ball valve in the heating circuit supply (4).
- 3** Open the ball valve in the heating circuit return (5).
- 4** Slowly open the ball valve in the primary supply (3) to fill the station.

i Connect a hose line to the drain valve (1) in the primary circuit to make it easier to direct escaping water into a container.

Have a cloth and a container ready to catch any water that escapes.

Regudis W-HTE

Commissioning

- 5 Open the drain valve (1) in the primary circuit.
 - 6 As soon as water escapes without bubbles, set the rotary knob ((7) in Fig. 7 on page 13) of the controller to the service mode index ((6) in Fig. 7 on page 13).
 - 7 As soon as water escapes without bubbles, close the drain valve (1).
 - 8 Open the vent valve (6) in the heating circuit slightly.
 - 9 As soon as water escapes without bubbles, close the vent valve (6).
 - 10 Set the rotary knob ((7) in Fig. 7 on page 13) of the controller to the desired hot water temperature (< 70 °C).
 - 11 Check all components and screw connections for leaks.
 - 12 If necessary, tighten loosened screw connections and replace defective seals.
- Filling and venting of the heating circuit is complete.



Impurities in the pipe can lead to deposits in the filter. For filter cleaning, see section 8.5 on page 41.

7.2 Filling of the potable water circuit




Fig. 29: Filling of the potable water circuit

- 1 Cold water inlet
- 2 Cold water outlet
- 3 Hot water outlet



CAUTION

Risk of scalding due to hot media!

If the heating system has been in operation and the connected buffer storage cylinder is heated, there is a risk of scalding due to unintentional escape of hot water or steam.

- ! Check all screw connections during filling and tighten any leaking screw connections.

NOTICE

Risk of damage due to pressure surge!

The abrupt injection of water into the station can lead to damage, e.g. to the sensors or sealing points.

- ! Always open the ball valves slowly.

- 1 Slowly open the ball valve in the cold water inlet (1) to fill the station.
 - 2 Slowly open the ball valve in the hot water outlet (3).
 - 3 Slowly open the ball valve in the cold water outlet (2).
 - 4 Open the draw-off point furthest away and tap hot and cold water until the potable water comes out without bubbles.
 - 5 Close the draw-off point.
 - 6 Check all components and screw connections for leaks.
 - 7 If necessary, tighten loosened screw connections and replace defective seals.
- Filling of the potable water circuit is complete.

7.3 Venting of the circulation pipe (if available)




Fig. 30: Circulation pipe

- 1 Vent valve
- 2 Circulation pipe
- 3 Primary return

4 Primary supply

CAUTION

Risk of scalding due to hot media!

If the heating system has been in operation and the connected buffer storage cylinder is heated, there is a risk of scalding due to unintentional escape of hot water or steam.

- ! Close the ball valves in the primary supply (4) and primary return (3).
- ! Allow the dwelling station to cool down.
- ! Wear safety goggles.

- 1 Open the vent valve (1).
 - 2 Slowly open the ball valve in the circulation pipe (2).
 - 3 As soon as water escapes without bubbles, close the vent valve (1).
 - 4 Slowly open the ball valves in the primary return (3) and primary supply (4).
- Venting of the circulation pipe is complete.

7.4 Setting of the ball valves and valves for operation




Fig. 31: Setting of the ball valves and valves for operation

- 1 Drain valve
- 2 Ball valve
- 3 Zone valve
- 4 Vent valve

- Set the ball valves and valves of the station for operation:
- The ball valves (2) under the station must be open

(vertical).

- The zone valve (3) must be open.
 - The vent valve (4) and the drain valve (1) must be closed.
- Set the heating system (e.g. pump and shutoff valve) for operation of the station.

7.5 Setting of the hot water temperature




Fig. 32: Setting of the hot water temperature

- 1 Actuator with integrated potable water temperature control
- 2 Rotary knob

DANGER

Danger to life due to legionella formation!

If the hot water temperature is too low, then legionella can form in systems with circulation pipe.

- ! For systems with a circulation pipe, set the hot water temperature on the actuator (1) to at least 60 °C.
- ! Make sure that the heating water temperature in the buffer storage cylinder is set to at least 60 °C.
- ! Check that the temperature difference between the hot water outlet of the heat exchanger (e.g. 60 °C) and the return of the circulation pipe at the station (≥ 55 °C) does not exceed 5 °C.

- Observe the notes on scald protection in section 2.6.4 on page 9.

- Set the desired hot water temperature with the rotary knob (2) on the actuator (1).

7.5.1 Sliding hot water temperature control

If the desired hot water temperature cannot be reached because the storage cylinder temperature is too low, the temperature setting on the actuator for the hot water is automatically reduced to the max. achievable value. This

state is maintained until the storage cylinder temperature is sufficient to achieve the desired hot water temperature.



If necessary, check the set storage cylinder temperature.

7.6 Setting of the derivative temperature control set (if available)




Fig. 33: Setting of the derivative temperature control set

- 1 Handwheel
- 2 Scaled sleeve with marking



Do not set the temperature on the derivative temperature control higher than the hot water temperature set on the actuator.



A derivative temperature control set that is set too high causes a permanent bypass and leads to energy loss.

The derivative temperature control set is set too high if the value is higher than the possible primary flow temperature from the buffer storage cylinder.

- ▶ Set the temperature to the desired value on the handwheel (1) of the derivative temperature control set.

7.7 Setting of the heating circuit temperature (if a flow temperature control module is available)




Fig. 34: Setting of the heating circuit temperature

- 1 Temperature controller

Set the heating circuit temperature on the temperature controller (1) of the flow temperature control module to the desired temperature.



Please observe the separate instructions for the flow temperature control module.

7.8 Teaching-in of the actuator



Teaching-in of the actuator is mandatory for the intended function of the station.



The primary supply must be at operating temperature for the teach in-process.

- ▶ Open one or more hot water draw-off points and run the hot water at a constant hot water volume flow of more than 7 l/min for at least 5 minutes.

Meanwhile, the control parameters adapt to the conditions in the building's heating system.

7.9 Instruction of the operator

Explain the function and operation of the product to the operator!

- ▶ Commissioning is complete.

8. Troubleshooting

8.1 Troubleshooting table

MALFUNCTION	CAUSE	REMEDY
No heating of the potable water (only cold water at the draw-off points, LED lights up green).	The volume flow sensor is contaminated or defective.	Clean the volume flow sensor (see section 8.4 on page 39). If this does not solve the problem, replace the volume flow sensor.
No heating of the potable water (only cold water at the draw-off points, LED off).	The actuator with integrated potable water control is not in operation (de-energised).	Check the power supply to the actuator and restore the power supply if necessary.
No heating of the potable water (only cold water at the draw-off points, LED flashes green).	There is an air inclusion in the heating circuit.	Vent the heating circuit (see section 7.1 on page 30).
	The filter insert in the primary supply is clogged.	Clean or replace the filter insert (see section 8.5 on page 41).
	The heating system has a malfunction.	Remedy the malfunction.
The hot water temperature at the draw-off point(s) drops.	The heating water temperature is too low.	Increase the heating water temperature in the buffer storage cylinder. If necessary, check the output of the heat generator.
	The storage cylinder capacity is not sufficient.	Check the system design and increase the storage cylinder capacity if necessary.
During tapping, hot water temperatures fluctuate.	The control parameters do not match the conditions present in the object.	Teach in the actuator (see section 7.8 on page 33) to adapt the control to the conditions in the building's heating system.
	The temperature sensor at the hot water outlet ((13) in Fig. 3 on page 11) is defective.	Replace the temperature sensor (item no. 1344494). If necessary, contact the technical customer service (see section 1.4 on page 7)
During circulation operation, the water at the draw-off point cools down abruptly.	Cold water flows directly into the circulation pipe instead of into the heat exchanger.	Check the function of the check valve of the potable water circulation module (see section 9.1 on page 42). Replace a defective check valve.
With larger draw-off quantities, the target temperature is no longer reached.	The heating water temperature is not sufficient for the requested draw-off quantity.	Increase the heating water temperature in the storage cylinder (see characteristic lines in appendix).
	The heat exchanger is contaminated or calcified.	Clean the heat exchanger (see section 8.3.2 on page 38).
	The volume flow of the heating water is too low.	Check the system design and increase the pump capacity in the primary supply from the buffer storage cylinder if required.
	The filter insert in the primary supply is contaminated.	Clean or replace the filter insert (see section 8.5 on page 41).
Leakage at the heat exchanger (external).	Leakage at the heat exchanger due to corrosion. This can be the result of a brazing material that is unsuitable for the potable water quality.	Replace the heat exchanger. The brazing material must be suitable for the potable water quality (see information sheet "Notes on corrosion protection" in the appendix).
Pressure increase in the primary circuit (potable water enters the heating circuit). The safety valve in the primary circuit may be triggered.		

Regudis W-HTE

Troubleshooting

MALFUNCTION	CAUSE	REMEDY
The hot water volume flow at the draw-off point is too low.	The heat exchanger is heavily calcified.	Decalcify the heat exchanger (see section 8.3.2 on page 38).
	The cold water pressure is too low (pressure reducer incorrectly set).	Check the setting of pressure reducer and increase the setting if necessary.
The dwelling heating circuit does not get warm.	The filter insert in the primary supply is contaminated.	Clean or replace the filter insert (see section 8.5 on page 41).
	The zone valve is erroneously closed.	Open the zone valve.
	During operation with the flow temperature control module: the components are incorrectly set or defective.	Check the settings or replace defective components. Please observe the separate operating instructions of the flow temperature control module.
The heat exchanger is also hot outside of hot water preparation. The water is heated in an uncontrolled manner.	The service mode is active.	Set the rotary knob to the desired hot water temperature (see section 8.2 on page 35).
	The control valve is contaminated or blocked.	Dismantle the actuator from the control valve. Manually push down the valve spindle several times to check that it moves smoothly. If the valve spindle is blocked, contact the technical customer service (see section 1.4 on page 7).

8.2 Status messages and error messages at the actuator




Fig. 35: Status messages and error messages at the actuator

- 1** Indicator light (LED)
- 2** Rotary knob
- 3** Error reset index (only for specialist tradespeople)
- 4** Service mode index (only for specialist tradespeople)

The indicator light (1) of the actuator shows status messages and error messages.

Regudis W-HTE

Troubleshooting

8.2.1 Status messages

Indicator light	Description
LED lights up green	Normal operation, no hot water tapping.
LED flashes green	Normal operation, hot water tapping.
LED lights up orange	Calibration run or service run.
LED lights up red	Service mode active, actuator fully retracted.

8.2.2 Error messages

Indicator light: Flash codes	Error	Description
1x orange, 1x red	Potable water temperature sensor	Sensor delivers incorrect or no measured values.
1x orange, 2x red	Actuator	Unexpected motor blockage during control mode.
1x orange, 3x red	Actuator	Calibration run failed.
1x orange, 4x red	Supply voltage	Supply voltage too high, too low or not available.
1x orange, 5x red	Internal energy store	Faulty energy store, fail-safe mode no longer possible.
1x orange, 6x red	Temperature sensor housing	Sensor delivers incorrect or no measured values.
1x orange, 7x red	Volume flow sensor	Implausible volume flow value.
1x orange, 8x red	Setpoint generator	Implausible setting.
1x orange, 9x red	Electronics	-
1x orange, 10x red	Internal memory (EEPROM)	Memory error
red; flashing	Temperature sensor housing	The temperature is outside the recommended ambient temperature (see section 3.6 on page 15)

8.2.3 Fail-safe mode

The fail-safe mode becomes active as soon as one of the listed errors occurs. In fail-safe mode, the actuator closes the control valve to prevent uncontrolled heating of potable water. The fail-safe mode is active as long as an error is present.

When the cause of the error has been corrected, most error messages are automatically reset and the fail-safe mode is deactivated. Only the actuator errors have to be reset manually by an error reset.

8.2.4 Error reset

If the rotary knob is set to the error reset index ((3) in Fig. 35 on page 35) for longer than 5 seconds, then the displayed error is reset and a calibration run is started. As long as the rotary knob is set to the error reset index ((3) in Fig. 35 on page 35), a calibration run of the actuator is started again and again, during which the closing point of the control valve is detected.

To perform the error reset, proceed as follows:

- ▶ Set the rotary knob to the error reset index ((3) in Fig. 35 on page 35) for longer than 5 seconds to reset an error.
- ▶ After an error reset, set the rotary knob back to the desired hot water temperature (< 70 °C) to switch to normal operation.



If the power supply to the controller is interrupted and restored, then an error reset takes place automatically.

8.3 Calcification of the heat exchanger



DANGER

Danger to life due to electric current!

During some work, the actuator must remain in operation and the station must not be disconnected from the power supply. There is a risk of electric shock in the connection box.

- ! Do not open the connection box.
- ! The connection box must only be opened by a qualified electrician.



WARNING

Risk of injury from pressurised media!

Media escaping under pressure can cause injuries.

- ! Only carry out installation work when the system is depressurised.
- ! For retrofitting an existing system: Drain the system or shut off the supply pipes of the system section and depressurise the system section.
- ! Wear safety goggles.
- ! Any work on the system may only be carried out by specialist tradespeople.



CAUTION

Risk of scalding due to hot media!

During some work, the station has to remain in operation and there is a risk of scalding due to unintentional escape of hot water or steam.

- ! Allow the system to cool down.
- ! Wear safety goggles.

Regudis W-HTE

Troubleshooting

CAUTION

Risk of burns on hot components!

Touching hot components can cause burns.

- ! Wear safety gloves.

8.3.1 Recognition of calcification



Due to the high temperatures in the station, calcification of the installed heat exchanger cannot be ruled out in principle. This applies especially when installing a circulation pipe.

The following signs indicate calcification or contamination of the heat exchanger:

- With larger draw-off quantities, the temperature drops below the set hot water temperature.
- The set hot water temperature is only reached with small draw-off quantities.
- The hot water volume flow is reduced compared to the cold water volume flow.

If these symptoms occur, you must decalcify the potable water side or clean the heating circuit side of the heat exchanger.

8.3.2 Removal and cleaning of the heat exchanger

DANGER

Danger to life due to electric current!

There is a danger to life if live components are touched.

- ! Disconnect the station from the power supply at all poles and secure it against being switched on again.
- ! Check that no voltage is present.




Fig. 36: Removal and cleaning of the heat exchanger

- 1 Drain valve

- 2 Ball valve

- 3 Heat exchanger

- 4 Control valve with integrated differential pressure and volume flow control

- 5 Vent valve

CAUTION

Risk of scalding due to hot media!

When working on the station, there is a risk of scalding due to unintentional escape of hot water or steam.

Close all ball valves (2) below the station and allow the water in the station to cool down.

CAUTION

Risk of burns on the heat exchanger!

Components become very hot during operation and there is a risk of burns if touched.

- ! Allow the station cool down.



Incorrect cleaning/decalcification leads to damage to the natural passive layer and an increased risk of corrosion of the plate material.

- 1 Open the ball valve in the hot water outlet ((3) in Fig. 29 on page 31).
- 2 Open a draw-off point to depressurise the potable water circuit.
- 3 When the potable water circuit is depressurised, close the draw-off point again.
- 4 Disconnect the cables from the actuator.
- 5 Dismantle the actuator.



Connect a hose line to the drain valve ((1) in Fig. 3 on page 11) in the primary circuit to make it easier to direct escaping water into a container.

Have a cloth and a container ready to catch any water that escapes.

- 6 Open the vent valve (5) and the drain valve (1) to depressurise and drain the heating circuit.
- 7 Close the vent valve (5) and the drain valve (1).
- 8 Loosen the screw connections between the control valve (4) and the pipework.
- 9 Lift the control valve out of the station.
- 10 Loosen the screw connections between the heat exchanger (3) and the pipework.
- 11 Lift the heat exchanger out of the station.
- 12 Clean the heat exchanger with a suitable cleaning agent. Follow the cleaning agent manufacturer's instructions.
- 13 Lift the cleaned heat exchanger into the station.



The G 1 connection on the heat exchanger is intended for connection to the control valve.

- 14 Screw the heat exchanger to the pipework.
- 15 Mount the control valve (4) with actuator in the station.
- 16 Connect the cables to the actuator.
- 17 Fill the potable water circuit as described in section 7.2 on page 31.
- 18 Fill and vent the heating circuit as described in section 7.1 on page 30.

8.4 Inspection and cleaning of the volume flow sensor




Fig. 37: Inspection and cleaning of the volume flow sensor

- 1 Volume flow sensor
- 2 Ball valve
- 3 Actuator with integrated potable water temperature control

8.4.1 Inspection of the flow sensor

A malfunction occurs when no hot water can be tapped at the draw-off points. This can have several causes (see section 8.1 on page 34).

- ▶ Rule out causes that are easy to determine, e.g. de-energised actuator (3) or missing contact of the signal line of the volume flow sensor.
- ▶ Check the volume flow sensor (1) for contamination by tapping potable water and observing the indicator light on the actuator:
 - When not hot water is being tapped or outside circulation mode, the indicator light on the actuator is permanently green.
 - When tapping hot water or during circulation mode, the indicator light flashes green.

- If the indicator light is permanently green when tapping hot water, the volume flow sensor may be contaminated.

If the volume flow sensor is contaminated, then the volume flow of the cold water inlet or of the cold water inlet with circulation pipe is not detected and no hot water tapping is registered. This means that the control is not activated and no energy is transferred to the potable water circuit in the heat exchanger.

8.4.2 Cleaning of the volume flow sensor



DANGER

Danger to life due to electric current!

There is a danger to life if live components are touched.

- ! Disconnect the station from the power supply at all poles and secure it against being switched on again.
- ! Check that no voltage is present.

If the volume flow sensor is contaminated:

- 1 Close the ball valves in the cold water inlet and cold water inlet and cold water outlet ((2) in Fig. 37 on page 39) in the potable water circuit.
- 2 Open a draw-off point to depressurise the potable water circuit.
- 3 When the potable water circuit is depressurised, closed the draw-off point again.




Fig. 38: Loosening of the safety clip

- 1 Volume flow sensor
- 2 Safety clip
- 4 Loosen the safety clip at the volume flow sensor.
- 5 Remove the volume flow sensor from the housing.




Fig. 39: Removal of the volume flow sensor

- 1 Cap
- 2 Union nut

- 6 Unscrew the cap (1) for the circulation connection.
- 7 Loosen the union nuts (2) of the volume flow sensor and remove the volume flow sensor from the pipes.




Fig. 40: Cleaning of the volume flow sensor under running water

- 1 Volume flow sensor housing

NOTICE

Risk of damage to the slide-in turbine!

The slide-in turbine is a sensitive component that can be easily damaged. The turbine wheel must rotate freely and smoothly after cleaning.

- ! Do not use pointed objects when cleaning the slide-in turbine.
- 8 Hold the volume flow sensor housing (1) under running water in the opposite direction to the flow direction to remove residues such as hemp residues and to clean the slide-in turbine.
- 9 Blow into the slide-in turbine to check that the turbine wheel turns freely and smoothly. If this is not the case, replace the volume flow sensor.




Fig. 41: Installation of the volume flow sensor

- 1 Volume flow sensor
- 2 Cap
- 3 Union nut

- 10 Screw the cap (2) tightly onto the circulation connection.
- 11 Insert the volume flow sensor into the housing and secure it with the safety clip.
- 12 Fit the volume flow sensor (1) onto the pipes and tighten the union nuts (3) of the volume flow sensor.
- 13 Connect the plug connection to the actuator.



Make sure the polarity is correct (the plugs are coded, see Fig. 7 on page 13).

- 14 Open the ball valves.
- 15 Perform a functional test as described in section 8.4.1 on page 39.
- ▷ The volume flow sensor is cleaned.

8.5 Cleaning of the filter insert

WARNING

Risk of injury from pressurised media!

Media escaping under pressure can cause injuries.

- ! Only carry out installation work when the system is depressurised.
- ! For retrofitting an existing system: Drain the system or shut off the supply pipes of the system section and depressurise the system section.
- ! Wear safety goggles.
- ! Any work on the system may only be carried out by specialist tradespeople.





Fig. 42: Cleaning of the filter insert

1 Plug

- 1** Close the ball valves in the primary supply ((3) in Fig. 28 on page 30), primary return ((2) in Fig. 28 on page 30), heating circuit supply ((4) in Fig. 28 on page 30) and heating circuit return ((5) in Fig. 28 on page 30).
 - 2** Slowly open the vent valve in the heating circuit ((16) in Fig. 3 on page 11) to depressurise the section.
 - 3** Close the vent valve in the heating circuit.
 - 4** Unscrew the plug (1) of the filter insert from the housing in the primary supply.
-
-  Have a cloth and a container ready to catch any water that escapes.
- 5** Pull the plug together with the screen out of the filter insert.
 - 6** Clean the screen under running water.
 - 7** Check the housing for dirt residues and remove them if necessary.
 - 8** Slide the screen and the plug into the filter insert and screw the plug into the housing.
 - 9** Slowly open the ball valves in the primary return and the primary supply.
 - 10** Open the vent valve in the heating circuit slightly.
 - 11** As soon as water escapes without bubbles, close the vent valve.

- 12** Check all components and screw connections for leaks.
 - 13** Tighten any screw connections that are too loose.
 - 14** Check the system pressure and top up with heating water if necessary.
- ▷ The filter insert is cleaned.

9. Maintenance

DANGER

Danger to life due to electric current!

During some work, the actuator must remain in operation and the station must not be disconnected from the power supply. There is a risk of electric shock in the connection box.

- ! Do not open the connection box.
- ! The connection box must only be opened by a qualified electrician.

WARNING

Risk of injury from pressurised media!

Media escaping under pressure can cause injuries.

- ! Only carry out installation work when the system is depressurised.
- ! For retrofitting an existing system: Drain the system or shut off the supply pipes of the system section and depressurise the system section.
- ! Wear safety goggles.
- ! Any work on the system may only be carried out by specialist tradespeople.

⚠ CAUTION

Risk of scalding due to hot media!

During some work, the station has to remain in operation and there is a risk of scalding due to unintentional escape of hot water or steam.

- ! Allow the system to cool down.
- ! Wear safety goggles.

⚠ CAUTION

Risk of burns on hot components!

Touching hot components can cause burns.

- ! Wear safety gloves.

9.1 Functional test of the check valve of the potable water circulation module




Fig. 43: Functional test of the check valve

- 1 Vent valve
- 2 Check valve

Only when using a potable water circulation module:



Please observe the separate instructions for the potable water circulation module.

The check valve (2) of the potable water circulation module must be checked annually for correct functioning according to DIN EN 806:

- 1 Close the ball valves in the hot water outlet ((3) in Fig. 29 on page 31) and the circulation pipe ((2) in Fig. 30 on page 31).
- 2 Open the vent valve (1) to depressurise the circulation pipe.

If potable water continuously leaks from the vent valve, the check valve is defective and you must replace the check valve.

9.2 Leakage test (visual inspection)

Due to the temperature fluctuations caused by operation, of the temperature changes caused by operation, we recommend that you check the screw connections and seals manually for correct functioning.

- 1 Check all interfaces to the outside of the piping and inside the station for moisture.
- 2 If necessary, tighten loosened screw connections and replace defective seals.

Moisture associated with discolouration on the heat exchanger indicates external corrosion that necessitates replacement.

- 3 Check the heat exchanger for moisture and discolouration and replace a defective heat exchanger immediately.

9.3 Inspection of the electrical components and plug connections




Fig. 44: Inspection of the electrical components

- 1 Connecting block for room thermostats and actuators
- 2 Circulation pump
- 3 Actuators for the surface heating system
- 4 Pump for the surface heating system
- 5 Contact thermostat

Regudis W-HTE

Notes for the operator

- 6** Control valve with integrated differential pressure and volume flow control
- 7** Actuator with integrated potable water temperature control

Check plug connections annually for correct seating.

- ▶ Check the electrical components (1, 2, 3, 4, 5) connected to the station for integrity and firm seating.
- ▶ Check the cable plug connections of all components connected to the actuator (7).
- ▶ Check the tight screw connection of the actuator (7) on the control valve (6).

9.4 Performance test of the heat exchanger

To exclude calcification and contamination of the heat exchanger, we recommend that you check the performance of the heat exchanger annually.

- 1** Tap hot water at several draw-off points at the same time without adding cold water.
- 2** Measure the hot water temperature at the draw-off point furthest away from station.
- 3** Compare the measured hot water temperature with the hot water temperature set on the actuator.

The performance of the heat exchanger is correct if the measured hot water temperature is not more than 5 °C higher or lower than the hot water temperature set on the actuator (e.g. 60 °C).

If the difference is more than 5 °C:

- ▶ Check the filter insert.
- ▶ Check the flow temperature.
- ▶ Check the volume flow sensor or differential pressure.
- ▶ Clean and decalcify the heating exchanger as described in section 8.3 on page 37.

10. Notes for the operator



The operator must have himself instructed by the specialist sanitary, heating and air-conditioning tradespeople in the safe and intended use of the station.

10.1 Setting of the hot water temperature




Fig. 45: Setting of the hot water temperature

- 1** Actuator with integrated potable water temperature control
- 2** Rotary knob

The hot water temperature can be set with the rotary knob (2) of the actuator (1) and is preset to 60 °C. The hot water temperature set and measured by the temperature sensor directly at the hot water outlet of the heat exchanger is slightly higher than the hot water temperature at the draw-off points.

- 1** Set the desired hot water temperature with the rotary knob of the actuator.
- 2** Tap hot water at the furthest draw-off point without adding cold water and check the hot water temperature. Adjust the hot water temperature if necessary.



Increasing the hot water temperature always means increasing the energy consumption and decreasing the hot water temperature always means saving energy.

10.2 Legionella prevention

Legionella multiply quickly if the hot potable water temperature is constantly too low or if the water is left standing for a longer time (> 72 h) without being tapped.

- ▶ Tap hot and cold water regularly to ensure a regular exchange of potable water and to prevent prolonged stagnation of the potable water.
- ▶ After each stagnation from 72 h, run the hot and cold

Regudis W-HTE

Dismantling and disposal

water at all draw-off points for a short time to exchange the potable water in the pipes.

Only in systems with circulation pipe:

- ▶ Set the hot water temperature at the actuator to at least 60 °C.
- ▶ Make sure that the heating water temperature in the buffer storage cylinder is set to more than 60 °C.



Observe the relevant regulations (e.g. DVGW work sheet W551).

11. Dismantling and disposal

11.1 Dismantling

11.1.1 Disconnection of the station from the power supply



DANGER

Danger to life due to electric current!

There is a danger to life if live components are touched.

- ! Disconnect the station from the power supply at all poles and secure it against being switched on again.
- ! Check that no voltage is present.
- ! Dismantling may only be carried out by a qualified electrician.

- 1 Disconnect the system from the power supply.
 - 2 Open the connection box.
 - 3 Disconnect the station permanently from the power supply.
- ▶ The station is de-energised and can be dismantled.

11.1.2 Dismantling of the station



CAUTION

Risk of injury from pressurised media!

Media escaping under pressure can cause injuries.

- ! Only carry out work when the system is depressurised.
- ! Close all ball valves on the station.
- ! Depressurise and drain the system section and the station.
- ! Wear safety goggles.
- ! Any work on the system may only be carried out by specialist tradespeople.



CAUTION

Risk of scalding due to hot media!

Escaping hot media can lead to scalding.

- ! Close all ball valves on the station and depressurise the station.
- ! Allow the water in the station to cool down.



CAUTION

Risk of burns from hot components!

Touching hot components can cause burns.

- ! Allow the station cool down.

- ▶ Dismantle the station.

- ▶ The station can be disposed of separately according to components.

11.2 Disposal

NOTICE

Risk of environmental pollution!

Incorrect disposal can lead to environmental damage.

- ! Dispose of packaging materials in an environmentally friendly manner.
- ! If possible, recycle the components.
- ! Dispose of non-recyclable components according to local regulations.

Directive 2012/19/UE WEEE:



- The "crossed-out wheeled bin" symbolises that you are legally obliged to dispose of old appliances separately from unsorted municipal waste. Incorrect disposal can lead to environmental damage.
- Remove used batteries and accumulators not enclosed in the old appliance as well as lamps from the old appliance without destroying them and dispose of them separately.
- You can hand in your old appliance free of charge within the framework of the possibilities provided by the public waste disposal authorities.
- Distributors with a sales area for electrical and electronic equipment of at least 400 square meters are obliged to take back your old appliance free of charge when you buy a similar new appliance (1:1 take-back). You can also return all old appliances to distributors free of charge if the external dimensions do not exceed 25 centimetres and the return is limited to three old appliances per type of appliance.
- Delete your personal data stored on the old device to be disposed of, if any, on your own responsibility.

12. Appendix

12.1 Characteristic line for heating mode

Pressure loss during heating mode for performance ranges 1 to 3 and double-walled version
-Heating circuit -




Fig. 46: Pressure loss during heating mode

12.2 Characteristic lines for potable water mode




Fig. 47: Pressure loss in the potable water circuit




Fig. 48: Pressure loss in the primary circuit




Fig. 49: Pressure loss in the primary circuit - double-walled version




Fig. 50: Pressure loss in the cold water outlet

12.3 Characteristic lines for performance range 1

Performance data according to SPF test procedure.




Fig. 51: Performance range 1, heating of potable water to 45 °C




Fig. 52: Performance range 1, heating of potable water to 45 °C




Fig. 53: Performance range 1, heating of potable water to 50 °C




Fig. 54: Performance range 1, heating of potable water to 50 °C




Fig. 55: Performance range 1, heating of potable water to 55 °C




Fig. 56: Performance range 1, heating of potable water to 55 °C




Fig. 57: Performance range 1, heating of potable water to 60 °C




Fig. 58: Performance range 1, heating of potable water to 60 °C

12.4 Characteristic lines for performance range 2

Performance data according to SPF test procedure.




Fig. 59: Performance range 2, heating of potable water to 45 °C




Fig. 60: Performance range 2, heating of potable water to 45 °C




Fig. 61: Performance range 2, heating of potable water to 50 °C




Fig. 62: Performance range 2, heating of potable water to 50 °C




Fig. 63: Performance range 2, heating of potable water to 55 °C




Fig. 64: Performance range 2, heating of potable water to 55 °C




Fig. 65: Performance range 2, heating of potable water to 60 °C




Fig. 66: Performance range 2, heating of potable water to 60 °C

12.5 Characteristic lines for performance range 3

Performance data according to SPF test procedure.




Fig. 67: Performance range 3, heating of potable water to 45 °C




Fig. 68: Performance range 3, heating of potable water to 45 °C




Fig. 69: Performance range 3, heating of potable water to 50 °C




Fig. 70: Performance range 3, heating of potable water to 50 °C




Fig. 71: Performance range 3, heating of potable water to 55 °C




Fig. 72: Performance range 3, heating of potable water to 55 °C




Fig. 73: Performance range 3, heating of potable water to 60 °C




Fig. 74: Performance range 3, heating of potable water to 60 °C

12.6 Characteristic lines for double-walled version

Performance data according to SPF test procedure.




Fig. 75: Double-walled version, heating of potable water to 45°C




Fig. 76: Double-walled version, heating of potable water to 45°C




Fig. 77: Double-walled version, heating of potable water to 50°C




Fig. 78: Double-walled version, heating of potable water to 50°C




Fig. 79: Double-walled version, heating of potable water to 55°C




Fig. 80: Double-walled version, heating of potable water to 55°C




Fig. 81: Double-walled version, heating of potable water to 60°C




Fig. 82: Double-walled version, heating of potable water to 60°C

12.7 Advice regarding corrosion protection

oventrop

Valves, controls + systems



Fresh water and dwelling stations

Advice regarding corrosion protection

The materials used in the Oventrop fresh water and dwelling stations are selected and processed in accordance with strict quality specifications. The material used for the heat exchanger plates (stainless steel 1.4401) has proven its worth in potable water installations over a long time. **Depending on the water quality, especially in case of high chloride concentrations > 100 mg/l, leaks caused by corrosion** at the heat exchanger can, however, not be excluded.

For this reason, the specifying engineer and/or the user of the system have to make sure that the fresh water and dwelling stations are only operated with **potable water** whose chemical composition **does not have a corrosive effect** on the components.

Consult your local water authority if necessary.

The below table shows limit values of substances in potable water when using heat exchangers with different **brazing materials** (copper, nickel or stainless steel).

It must be noted that **interactions** between certain substances in the water may have an adverse effect on the materials.

This concerns, amongst others, combinations of hydrogen carbonate with chloride and/or sulphate. (see next page).

The choice of a suitable heat exchanger therefore has to be carried out according to the water quality. Corresponding analyses can be obtained from your local water authority.

Demands on the water quality

SUBSTANCES	CONCENTRATION (mg/l or ppm)	Stainless steel heat exchanger brazed with:		
		COPPER	NICKEL / STAINLESS STEEL	COPPER with Sealix® protective layer
⚠ Chlorides (Cl ⁻) at 60 °C See chart on next page!	< 100 100 - 300 > 300	+ - -	+ - -	+ + 0
Hydrogen carbonate (HCO ₃ ⁻)	< 70 70 - 300 > 300	0 + 0	+ + +	+ + +
Sulphate (SO ₄ ²⁻)	< 70 > 70	+ -	+ +	+ +
HCO ₃ ⁻ / SO ₄ ²⁻	> 1.0 < 1.0	+ -	+ +	+ +
Electrical conductivity at 20 °C	< 50 µS/cm 50 - 500 µS/cm > 500 µS/cm	0 + 0	+ + +	+ + +
pH In general, a low pH value (below 6) increases the risk of corrosion and a high pH value (above 7.5) reduces the risk of corrosion.	< 6.0 6.0 - 7.5 7.5 - 9.0 9.0 - 9.5 > 9.5	0 0 + 0 0	0 + + + +	+ + + + 0
Free chlorine (Cl ₂)	< 1 > 1	+ -	+ -	+ 0
Ammonium (NH ₄ ⁺)	< 2 2 - 20 > 20	+ 0 -	+ + +	+ + -
Hydrogen sulphide (H ₂ S)	< 0.05 > 0.05	+ -	+ +	+ 0
Free (aggressive) carbon dioxide (CO ₂)	< 5 5 - 20 > 20	+ 0 -	+ + +	+ + +
Nitrate (NO ₃ ⁻)	< 100 > 100	+ 0	+ +	+ +
EXPLANATIONS:	+ Good resistance under normal conditions 0 Corrosion may arise - Use not recommended			

The chemical composition of the potable water may be subjected to temporal fluctuations.

Special advice regarding corrosion protection

NOTICE

High fluid temperatures (>60 °C) increase the risk of corrosion

- ▶ Do not set the hot water temperature and the flow temperature of the heating water higher than necessary.

NOTICE

Long stagnation periods increase the risk of corrosion

- ▶ Flush the installation manually or automatically at regular intervals if longer stagnation periods are to be expected continually (VDI/DVGW 6023).


- Be careful in case of hydrogen carbonate/chloride combinations. **Low hydrogen carbonate contents combined with high chloride contents increase the risk of corrosion.**
- Be careful in case of hydrogen carbonate/sulphate combinations. **When using copper brazed heat exchangers, the hydrogen carbonate content in the water must not be lower than the sulphate content.** If this is the case, a nickel brazed, stainless steel brazed or a heat exchanger with protective layer has to be used.
- If the substances in the water are outside the indicated limit values, a **water treatment system** has to be installed, if required.

NOTICE

An incorrectly operated water treatment system may increase the risk of corrosion!

- **In case of mixed installations, the "flow rule" must be observed when using copper brazed heat exchangers in combination with galvanised steel pipes.** More detailed information can be obtained from the DIN EN 12502 standard.
- **Flush all supply pipes before installation** of the station (DIN EN 806-4), to remove any dirt particles and residues from the system.
- During **maintenance work** on the station, please consider that even **detergents may encourage corrosion of the heat exchanger.** In this context, observe the DVGW specifications, such as the work sheets W291 and W319.
- **When using a copper brazed heat exchanger without protective layer, the electrical conductivity of the water lies between 50 and 500 µS/cm.** Bear this in mind particularly in the context of water treatment according to VDI2035.

Permissible chloride content depending on the temperature



A heat exchanger with Sealix® protective layer minimises the risk of corrosion even in case of higher temperatures and chloride contents. Refer to the table "Demands on the water quality" for the respective limit values.

NOTICE

Corrosion and formation of stones in the system

- ▶ The specifying engineer and the user of the system are responsible for incorporating and evaluating substances and other factors in the water, which could influence corrosion and the formation of stones in the system. In critical water supply areas, the local water authority should be consulted.

OVENTROP GmbH & Co. KG

Paul-Oventrop-Straße 1

D-59939 Olsberg

Phone +49 (0) 29 62 82-0

Fax +49 (0) 29 62 82-400

E-Mail mail@oventrop.de

Internet www.oventrop.com

134103144

V06.09.2020

12.8 EU Declaration of conformity

EU Declaration of Conformity



Product identification: Electronic dwelling station "Regudis W-HTE"

Manufacturer: Oventrop GmbH & Co. KG
 Address: Paul-Oventrop-Straße 1
 59939 Olsberg
 GERMANY

Authorised person for compiling the technical documentation: Oventrop GmbH & Co. KG
 Paul-Oventrop-Straße 1
 59939 Olsberg
 GERMANY

This declaration of conformity is issued under sole responsibility of the manufacturer.

Object of the declaration:

Item no.	Type
1344030	Plate heat exchanger performance range Type 1
1344031	Plate heat exchanger performance range Type 2
1344032	Plate heat exchanger performance range Type 3
1344050	Plate heat exchanger performance range Type 1, fully sealed
1344051	Plate heat exchanger performance range Type 2, fully sealed
1344052	Plate heat exchanger performance range Type 3, fully sealed
1344070	Plate heat exchanger double-walled Type DW

The object of the declaration described above is in conformity with the relevant Union harmonisation legislation:

Machinery directive

DIRECTIVE 2006/42/EC OF THE EUROPEAN PARLIAMENT AND OF THE COUNCIL of 17 May 2006 on machinery, and amending Directive 95/16/EC (recast)

The conformity of the product described above with the provisions of the applied Directive(s) is demonstrated by compliance with the following Standards/ regulations:

DIN EN ISO 12100:2011 + AC:2013
 DIN EN 60204-1:2019
 DIN EN 60730-1:2017

Electromagnetic Compatibility Directive

DIRECTIVE 2014/30/EU OF THE EUROPEAN PARLIAMENT AND OF THE COUNCIL of 26 February 2014 on the harmonisation of the laws of the Member States relating to electromagnetic compatibility

The conformity of the product described above with the provisions of the applied Directive(s) is demonstrated by compliance with the following Standards/ regulations:

EN 55014-1:2017 + A11:2020
 EN 55014-2:1997 + AC:1997 + A1:2001 + A2:2008
 EN 61000-3-2:2014
 EN 61000-3-3:2013
 DIN EN 60730-1:2017

RoHS

DIRECTIVE 2011/65/EU OF THE EUROPEAN PARLIAMENT AND OF THE COUNCIL of 8 June 2011 on the restriction of the use of certain hazardous substances in electrical and electronic equipment (recast)

Pressure Equipment directive

These articles fall under Article 4(3) of the Pressure Equipment Directive 2014/68/EU and are designed and manufactured in accordance with good engineering practice.

59939 Olsberg, 26.09.2023

Signed for and behalf of:
 Oventrop GmbH & Co. KG

i.V. 
 Hendrik Hössel
 Head of Development

i.V. 
 Thomas Droste
 Teamleader Systems



oventrop

Wir regeln das. Seit 1851.

Oventrop GmbH & Co. KG · Paul-Oventrop-Str. 1 · 59939 Olsberg
Tel. +49 2962 820 · Fax +49 2962 82400 · mail@oventrop.com · www.oventrop.com