

Raumfeuchte-Messumformer  
 Transmetteur de mesure d'humidité relative  
 Room transducer for relative humidity  
 Trasmittitore della umidità ambiente  
 Convertidor de la humedad ambiente  
 Rumsfuktighet-omvandlare  
 Ruimtevochtigheid-meetomvormer

Montagevorschrift  
 Instructions de montage  
 Fitting instructions  
 Istruzioni di montaggio  
 Instrucciones de montaje  
 Monteringsanvisning  
 Montagevoorschrift

H%	☐
T	☐ ☒

Y07596

Installationsanweisung für die Elektrofachkraft  
 Notice d'installation pour l'électricien  
 Guidelines for the electrician  
 Informazioni per l'installatore elettrico  
 Instrucciones de instalación para el electricista  
 Installationsinstruktion för behörig elektriker  
 Instalatie aanwijzing voor de elektromonteur

Für den Einsatz in üblicher Umgebung  
 Pour usage dans un environnement normal  
 For use in normal environments  
 Per impiego in ambiente usuale  
 Para el uso en ambiente normal  
 För användning i normal miljö  
 Voor toepassing in normale omgeving



