

Raumfeuchte-Messumformer
 Transmetteur de mesure d'humidité relative
 Room transducer for relative humidity
 Trasmittitore della umidità ambiente
 Convertidor de la humedad ambiente
 Rumsfuktighet-omvandlare
 Ruimtevochtigheid-meetomvormer

Montagevorschrift
 Instructions de montage
 Fitting instructions
 Istruzioni di montaggio
 Instrucciones de montaje
 Monteringsanvisning
 Montagevoorschrift

H%	☐
T	☐ ☒

Y07596

Installationsanweisung für die Elektrofachkraft
 Notice d'installation pour l'électricien
 Guidelines for the electrician
 Informazioni per l'installatore elettrico
 Instrucciones de instalación para el electricista
 Installationsinstruktion för behörig elektriker
 Instalatie aanwijzing voor de elektromonteur

Für den Einsatz in üblicher Umgebung
 Pour usage dans un environnement normal
 For use in normal environments
 Per impiego in ambiente usuale
 Para el uso en ambiente normal
 För användning i normal miljö
 Voor toepassing in normale omgeving



